

Přesné spojky LET-LOK® - adaptéry a redukční konektory (1)

METRICKÉ TRUBKY		Adaptér		Adaptér 90°			Konektor *	
vnější průměr trubky								
A [mm]	A1 [mm]	index (AISI 316)	L [mm]	index (AISI 316)	E [mm]	N1 [mm]	index (AISI 316)	L [mm]
3	3	-	-	-	-	-	HM-LM767LP-03-SS	22.2
3	6	HM-LM767LT-03-06-SS	36.1	-	-	-	-	-
3	10	HM-LM767LT-03-10-SS	38.4	-	-	-	-	-
4	6	HM-LM767LT-04-06-SS	37.1	-	-	-	-	-
6	2	-	-	-	-	-	-	-
6	3	HM-LM767LT-06-03-SS	36.9	-	-	-	HM-LM767LM-06-03-SS	22.9
6	6	-	-	HM-LM769LT-06-06-SS	27.0	23.8	HM-LM767LP-06-SS	25.0
6	8	HM-LM767LT-06-08-SS	36.9	-	-	-	-	-
6	10	HM-LM767LT-06-10-SS	40.7	-	-	-	-	-
6	12	HM-LM767LT-06-12-SS	46.3	-	-	-	-	-
6	18	HM-LM767LT-06-18-SS	49.6	-	-	-	-	-
8	6	HM-LM767LT-08-06-SS	40.3	-	-	-	HM-LM767LM-08-06-SS	24.7
8	8	-	-	HM-LM769LT-08-08-SS	-	-	HM-LM767LP-08-SS	25.9
8	10	HM-LM767LT-08-10-SS	42.0	-	-	-	-	-
8	12	HM-LM767LT-08-12-SS	47.6	-	-	-	-	-
10	6	HM-LM767LT-10-06-SS	42.4	-	-	-	HM-LM767LM-10-06-SS	25.8
10	8	HM-LM767LT-10-08-SS	43.4	-	-	-	HM-LM767LM-10-08-SS	26.1
10	10	-	-	-	-	-	HM-LM767LP-10-SS	27.1
10	12	HM-LM767LT-10-12-SS	49.8	-	-	-	-	-
10	15	HM-LM767LT-10-15-SS	51.3	-	-	-	-	-
10	18	HM-LM767LT-10-18-SS	51.3	-	-	-	-	-
12	6	HM-LM767LT-12-06-SS	44.9	-	-	-	HM-LM767LM-12-06-SS	29.1
12	8	HM-LM767LT-12-08-SS	45.9	-	-	-	HM-LM767LM-12-08-SS	29.8
12	10	HM-LM767LT-12-10-SS	46.7	-	-	-	HM-LM767LM-12-10-SS	30.6
12	12	-	-	HM-LM769LT-12-12-SS	38.0	40.4	HM-LM767LP-12-SS	36.2
12	16	HM-LM767LT-12-16-SS	53.8	-	-	-	-	-
12	18	HM-LM767LT-12-18-SS	53.8	-	-	-	-	-
12	20	HM-LM767LT-12-20-SS	56.1	-	-	-	-	-
12	22	HM-LM767LT-12-22-SS	56.1	-	-	-	-	-
12	25	HM-LM767LT-12-25-SS	62.4	-	-	-	-	-
14	14	-	-	-	-	-	HM-LM767LP-14-SS	-
15	10	HM-LM767LT-15-10-SS	-	-	-	-	-	-
15	15	-	-	HM-LM769LT-15-15-SS	38.0	41.0	-	-
16	12	HM-LM767LT-16-12-SS	53.0	-	-	-	HM-LM767LM-16-12-SS	37.5
16	16	-	-	HM-LM769LT-16-16-SS	-	-	HM-LM767LP-16-SS	37.4
18	12	HM-LM767LT-18-12-SS	54.6	-	-	-	HM-LM767LM-18-12-SS	-
18	16	HM-LM767LT-18-16-SS	56.1	-	-	-	-	-
18	18	-	-	-	-	-	HM-LM767LP-18-SS	37.4
18	20	HM-LM767LT-18-20-SS	57.6	-	-	-	-	-
18	22	HM-LM767LT-18-22-SS	57.6	-	-	-	-	-
18	25	HM-LM767LT-18-25-SS	62.4	-	-	-	-	-
20	10	-	-	-	-	-	-	-
20	12	HM-LM767LT-20-12-SS	-	-	-	-	-	-
20	16	HM-LM767LT-20-16-SS	57.9	-	-	-	-	-
20	18	HM-LM767LT-20-18-SS	57.9	-	-	-	-	-
20	20	-	-	-	-	-	HM-LM767LP-20-SS	-
20	22	HM-LM767LT-20-22-SS	59.4	-	-	-	-	-
20	25	HM-LM767LT-20-25-SS	64.2	-	-	-	-	-
22	10	-	-	-	-	-	-	-
22	16	-	-	-	-	-	-	-
22	18	HM-LM767LT-22-18-SS	57.9	-	-	-	-	-
22	20	HM-LM767LT-22-20-SS	59.4	-	-	-	-	-
22	22	-	-	HM-LM769LT-22-22-SS	44.6	50.0	-	-
22	25	HM-LM767LT-22-25-SS	64.2	-	-	-	-	-
25	12	-	-	-	-	-	HM-LM767LM-25-12-SS	-
25	18	HM-LM767LT-25-18-SS	63.1	-	-	-	HM-LM767LM-25-18-SS	-
25	20	HM-LM767LT-25-20-SS	64.6	-	-	-	-	-
25	25	-	-	HM-LM769LT-25-25-SS	-	-	HM-LM767LP-25-SS	-

* - spojky HM-LM767LM ... a HM-LM767LP - při montáži do spojky utáhněte matici ze strany kužele o 1/4 otáčky