

**Příslušenství pro pistole pro vysokotlaká mycí zařízení**

**Tryska pro nástavce**

**Materiál:** Nerez  
**Závit:** Vnější 1/4" NPT  
**Pracovní tlak:** do 350 bar

index	kalibrace	úhel paprsku	index	kalibrace	úhel paprsku
MH-170289	03	0°	MH-170334	03	25°
MH-170291	04		MH-170336	04	
MH-170292	045		MH-170337	045	
MH-170293	05		MH-170338	05	
MH-170294	055		MH-170339	055	
MH-170295	06		MH-170340	06	
MH-170296	065		MH-170341	065	
MH-170297	07		MH-170342	07	
MH-170299	08		MH-170344	08	
MH-170301	10		MH-170346	10	
MH-170308	03	15°	MH-170352	03	40°
MH-170310	04		MH-170354	04	
MH-170311	045		MH-170355	045	
MH-170312	05		MH-170356	05	
MH-170313	055		MH-170357	055	
MH-170314	06		MH-170358	06	
MH-170315	065		MH-170359	065	
MH-170317	07		MH-170360	07	
MH-170318	075		MH-170361	075	
MH-170319	08		MH-170362	08	
MH-170321	10	MH-170364	10		


**Tryska HYDROJET pro nástavce**

**Materiál:** Nerez  
**Závit:** Vnější 1/4" NPT  
**Pracovní tlak:** do 280 bar

index	kalibrace	úhel paprsku	index	kalibrace	úhel paprsku
MH-170216	03	0°	MH-170218	03	25°
MH-170224	04		MH-170226	04	
MH-170228	045		MH-170230	045	
MH-170232	05		MH-170234	05	
MH-170236	055		MH-170238	055	
MH-170240	06		MH-170242	06	
MH-170244	065		MH-170246	065	
MH-170602	07		MH-170604	07	
MH-170606	075		MH-170608	075	
MH-170610	08		MH-170612	08	
MH-170626	10	MH-170628	10	40°	
MH-170217	03	MH-170219	03		
MH-170225	04	MH-170227	04		
MH-170229	045	MH-170231	045		
MH-170233	05	MH-170235	05		
MH-170237	055	MH-170239	055		
MH-170241	06	MH-170243	06		
MH-170245	065	MH-170247	065		
MH-170603	07	MH-170605	07		
MH-170607	075	MH-170609	075		
MH-170611	08	MH-170613	08		
MH-170627	10	MH-170629	10		